



Floor Warming Thermostat

Dual Voltage

DS-606.2-0111



1. PRODUCT NAME

LATICRETE® Floor Warming Thermostat – Dual Voltage

2. MANUFACTURER

LATICRETE International, Inc.

1 LATICRETE Park North

Bethany, CT 06524-3423, USA

Telephone: +1.203.393.0010, ext. 235

Toll Free: 1.800.243.4788, ext. 235

Fax: +1.203.393.1684

Internet: www.laticrete.com

3. PRODUCT DESCRIPTION

LATICRETE Floor Warming Thermostat is a dual voltage 120V/240V simple to use digital programmable thermostat designed to be used with LATICRETE floor warming mats. All electrical connections must be made by a licensed electrician. Failure to do so will void all warranties and claims. Comply with all applicable building and electrical codes.

Features

- Advanced floor control maximizes comfort and energy savings
- 15 A (res.) 60 Hz
- 15 ft. sensor (4.5 m) included
- Easily accessible floor sensor connector
- Built-in GFCI with test light
- 7-day programmable
- On/off switch

Parts

- One (1) power base
- One (1) Sensor Probe
- Two (2) screws
- Four (4) solderless connectors for copper wires

4. TECHNICAL DATA

Model	Supply	Max. Load	Power	Wiring	GFCI
0800-0003-2	120V / 240V	15 A, 60 Hz	1800 W / 3600 W	4w/DP	5 mA

Storage: -4°F to 120°F (-20°C to 50°C)

Size (H x W x D) 4.89 x 2.76 x 0.91 in. (124 x 70 x 23 mm)

5. INSTALLATION

Guidelines

Turn off power to the heating system at the main electrical panel to avoid electrical shock. The installation should be carried out by an electrician. See Installation instructions provided with unit – DS 601.1

6. AVAILABILITY AND COST

Availability

LATICRETE Floor Warming products are available in North America.

For distributor information:

Toll Free: 1.800.235.4788

Telephone: +1.203.393.0010

Internet: www.laticrete.com

Cost

Contact a LATICRETE Distributor in your area.

7. WARRANTY

See 10. FILING SYSTEM

DS 230.13: LATICRETE Product Warranty

8. MAINTENANCE

The Internal LATICRETE Floor Warming Thermostat GFCI (Ground Fault Circuit Interrupt) should be tested monthly to ensure continued safe operation. If an external GFCI is utilized, it should also be tested monthly.

9. TECHNICAL SERVICES

Technical assistance

Information is available by calling:

Toll Free: 1.800.243.4788, ext. 235

Telephone: +1.203.393.0010, ext. 235

Fax: +1.866.537.4638

To acquire technical and safety literature, please visit our website at Floorwarming@laticrete.com.

10. FILING SYSTEM

DS 230.13: LATICRETE Product Warranty

DS 605.0: LATICRETE Floor Warming Mat

DS 601.1: Installation Instruction Guide

LATICRETE International, Inc.

One LATICRETE Park North, Bethany, CT 06524-3423 USA • 1.800.243.4788 • +1.203.393.0010 • www.laticrete.com

©2011 LATICRETE International, Inc.

LATICRETE, LATAPOXY, SPECTRALOCK and the  logo are Registered Trademarks of LATICRETE International, Inc.