




LATICRETE® 9235 Waterproofing Membrane Corner Treatments TDS 188

INSIDE AND OUTSIDE CORNERS

- Cut a 6" (150mm) long piece from the 6" (150mm) wide LATICRETE Waterproofing/Anti-Fracture Fabric roll, making a 6"x6" (150mm x 150mm) square;



- Make a cut from the center of one edge halfway to the center of the square, shown in drawing
- Cover corner surfaces with a liberal coat of LATICRETE 9235 Waterproofing Membrane Liquid, approximately 8" (200mm) wide [i.e. apply approximately 4" (100mm) of LATICRETE 9235 Waterproofing Membrane Liquid over the wall and floor surfaces bordering the corner];
- Place the *uncut* half of the square into the LATICRETE 9235 Waterproofing Membrane Liquid spread on the *wall*;
- Press the square firmly into the *wall* with a brush, allowing the LATICRETE 9235 Waterproofing Membrane Liquid to completely bleed through and saturate the LATICRETE Waterproofing/Anti-Fracture Fabric;
- Then place Tab A of the square into the LATICRETE 9235 Waterproofing Membrane Liquid spread on the *floor*;
- Press Tab A firmly into the *floor* with a brush, allowing the LATICRETE 9235 Waterproofing Membrane Liquid to completely bleed through and saturate the LATICRETE Waterproofing/Anti-Fracture Fabric;
- Apply additional LATICRETE 9235 Waterproofing Membrane Liquid over Tab A and fold Tab B over Tab A;
- Press Tab B firmly with a brush, allowing the LATICRETE 9235 Waterproofing Membrane Liquid to completely bleed through and saturate the LATICRETE Waterproofing/Anti-Fracture Fabric;
- Then apply another liberal coat of LATICRETE 9235 Waterproofing Membrane Liquid over the entire surface of the square just installed;
- Inspect the surface for pinholes and apply additional LATICRETE 9235 Waterproofing Membrane Liquid as needed;
- Once the last coat of LATICRETE 9235 Waterproofing Membrane Liquid has dried to the touch, proceed with the main application of LATICRETE 9235 Waterproofing Membrane - making sure that the LATICRETE 9235 Waterproofing Membrane is flashed 3" (75mm) up the walls at all cove areas.

* The above mentioned technique also applies to LATICRETE Hydro Ban™ (if needed).

Technical Data Sheets are subject to change without notice. For latest revision, check our website at www.laticrete.com
TDS 188.doc R 4 June 2009



LATICRETE INTERNATIONAL, INC. ▪ 1 LATICRETE Park North ▪ Bethany, CT 06524-3423 USA
800.243.4788 ▪ support@laticrete.com ▪ www.laticrete.com

©2009 LATICRETE INTERNATIONAL, INC. LATICRETE, LATAPOXY, SPECTRALOCK and the  logo are Registered Trademarks of LATICRETE International, Inc.