



Resilient Flooring Adhesives and LATICRETE® Membranes TDS 412

Compatibility questions can arise when resilient flooring (sheet goods and vinyl composition tile {V.C.T.} and other types of flooring materials (e.g. wood flooring, indoor / outdoor carpet, rubber flooring, etc.) are specified to be used over LATICRETE® Waterproofing and Anti-Fracture Membranes.

In order to avoid any compatibility issues, use a non-solvent based adhesive to install the flooring over the LATICRETE Membranes. Most water based latex adhesives will be compatible with LATICRETE Membranes.

An alternative approach to this situation, a 1/16" to 1/8" (1.5mm to 3mm) thick skim coating of a latex fortified LATICRETE Thin Set Mortar (e.g. LATICRETE 254 Platinum or LATICRETE 211 Powder mixed with LATICRETE 4237 Latex Additive) can be troweled over the hardened LATICRETE Membrane in order to protect the membrane.

Allow the latex thin set mortar skim coat to cure for a minimum of 12 to 24 hours at 70° F (21° C) prior to the installation of the resilient flooring.

Consult the resilient adhesive manufacturer for confirmation that their products are compatible with the latex rubber based membranes.

Additionally, do not use mechanical fasteners to install hardwood flooring or transition strips over LATICRETE Membranes. LATICRETE Membranes are not self-healing. Therefore, puncturing the membranes would void any warranties.

Technical Data Sheets are subject to change without notice. For latest revision, check our website at www.laticrete.com
TDS 412.doc R 24 January 2008

LATICRETE INTERNATIONAL, INC.
One LATICRETE Park North, Bethany, CT 06524-3423 USA • 800.243.4788 • 203.393.0010 • www.laticrete.com

©2007 LATICRETE INTERNATIONAL, INC.
LATICRETE, LATAPOXY and the  logo are Registered Trademarks of LATICRETE International, Inc.